

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

**PolyHide Lightning™
(MR-PH series)**

QUICK FACTS

- Paste: Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality clear, strippable, pre-mixed, vinyl adhesive.
- Prepaste the wall.
- Level 5 finish.
- Please read the following installation instructions before proceeding.
- **IF YOU DO NOT FOLLOW OUR INSTALLATION INSTRUCTIONS, MAYA ROMANOFF WILL NOT ACCEPT RESPONSIBILITY FOR THE INSTALLATION—YOU WILL BE INSTALLING AT YOUR OWN RISK.**

GENERAL GUIDELINES

- Inspect goods carefully. No returns on cut goods. Grade carefully for color flow.
- Confirm that you have the correct color and product before installing. Additional yardage from this dye lot may not be available.
- **No allowances will be made after THREE (3) drops—Call 800.465.6909 immediately if you encounter any difficulties.**
- No claims allowed for labor charges or consequential damages under any conditions.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.

ACTIONS TO AVOID

- Do not paste fabric.
- Do not stand rolls on end.
- Do not rub face of the product with a stiff brush.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Do not let paste dry on the face of the product.
- Avoid direct or bright reflected sunlight. Not guaranteed against fading or color change.

05/01/11

CONTINUED 



MAYA ROMANOFF

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 † 1.773.465.6909 † 1.773.465.7089 www.mayaromanoff.com

1

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

**PolyHide Lightning™
(MR-PH series)**

WALL PREPARATION

- Paint the wall the color of the product with a good quality, non-sealing flat latex wallpaint.
- Do not install on sealed walls without hanging lining paper.
- Walls should be mirror-smooth—a level 5 finish.
- Walls must be completely dry before installation can begin.

ADHESIVE

- **Paste wall directly. Do not paste the wallcovering!** Apply paste thicker where seams will fall. Allow 2-3 minutes for paste to tack up.
- Use Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality CLEAR, STRIPPABLE, PRE-MIXED, VINYL adhesive*.
- Pre-paste wall at seams and allow to dry.
- Avoid getting paste on face of the wallcovering.

TRIMMING

- Trim with a very sharp, single edge razor blade to true. USE A NEW BLADE FOR EACH CUT.

HANGING

- Smooth product to the wall using a plastic smoother. Smooth continuously to remove any bubbles.
- Do not smooth face of product with a bristle brush or any other textured smoothing implement.
- If needed, use a level or straight edge as a guide when hanging.

CARE

Keep surfaces looking great with proper maintenance. Clean regularly to prevent excessive dirt from accumulating. Follow these non-toxic guidelines to extend the life of the fabric:

- Clean regularly with soap and water
- Wipe up spills as soon as they occur
- Remove stains with an alcohol-based cleaner like Fantastik®
- Disinfect using a 5:1 water/bleach solution
- Thoroughly rinse all cleaning solution residue with water
- Air dry

*For more information on Maya Romanoff's MR-RA-838-1 or MR-RA-838-5, check out www.mayaromanoff.com.



05/01/11



MAYA ROMANOFF®

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 t 1.773.465.6909 f 1.773.465.7089 www.mayaromanoff.com