

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

APPLICATION INSTRUCTIONS

**CRYSTALLIZED™ Swarovski Elements
(MR-SWC1-00 and SWP1-01 series)**

For application on Ajiro Sunburst™ wood veneer wallcovering.

PREPARATION

- Install wallcovering according to installation instructions.
- Ensure area is clean and dry prior to crystal application.

ADHESIVE

- Use Scotch™ Super Glue Gel adhesive* (provided with the crystals).
- Read and follow carefully the instructions on Super Glue Gel packaging for optimal performance.
- Apply glue sparingly to the center of each Sunburst repeat. No more than one small drop of glue should be applied to the center of each Sunburst repeat. Excess glue could result in permanent damage to the face of the wallcovering.

APPLICATION

- Using your fingers or a set of tweezers, set the CRYSTALLIZED™ - Swarovski Element to the surface of the wallcovering. Press the embellishment against the wallcovering for approximately 15 seconds before releasing.

*An alternative fast-drying super-strength adhesive may be used to apply the crystals. Maya Romanoff makes no claims or guarantees for any other brand adhesive than Scotch™ Super Glue Gel.

05/01/11



M A Y A R O M A N O F F

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 † 1.773.465.6909 ‡ 1.773.465.7089 www.mayaromanoff.com